Doc. Number:	15227	Approvals			
Revision:	1		Signature	Date	
File Name:	CBL15227R1.doc	Engineering:			
Title:	Assembly Instructions: Cable, Test, Serial, Taurus 3-Port	Production:			
Originator:	Joseph Czompo				
Date:	2004/09/29				

Revision History:

Label 1: "Serial 1" Label 2: "Serial 2" Label 3: "Console" Label 4: Line 1:

Rev.	Date	Author	Description
1	Sept. 29, 2004	JC	Initial Revision

Assembly Instructions:

Cable, Test, Serial, Taurus 3-Port

- 1. Obtain all parts on the parts list BOM15227 (latest rev) and assemble the cable as shown in Fig. 1 and Table 1. Use document 12445 as a quide when assembling connector P4.
- 2. Use heat shrink on all solder connections and at each connector.
- 3. The cable must be checked electrically after assembly.

"BOM15227RX"

4. Install the labels approximately 5 cm from their corresponding connectors. In place of X on Label 4, insert the revision number of the BOM actually used. The label text on the various labels is as follows:




Figure 1: Cable assembly

From			То			Wire			
Conn.	Pin	Name	Conn	Pin	Name	Part	Colour	AWG	Туре
P4	Р	S1_RX	P1	3	S1_RX	W1			
P4	N	S1_TX	P1	2	S1_TX	W1			
P4	V	GND	P1	5	GND	W1			
P4	F	S2_RX	P2	3	S2_RX	W2			
P4	G	S2_TX	P2	2	S2_TX	W2			
P4	V	GND	P2	5	GND	W2			
P4	С	S1_DSR	P3	3	CO_RX	W3			
P4	В	S1_DTR	P3	2	CO_TX	W3			
P4	V	GND	P3	5	GND	W3			

1. Table 1: Wiring list